



# CP-2150

**1948-54 Ford 1/2tn Pickup Small/Big Block Chevy Engine Mount Kit**  
for use on vehicles with original front suspension

- 1** Remove original engine and transmission
- 2** Slide frame mounts inside frame rails and clamp in place using measurements shown.
- 3** Check that mounts are centered side to side and front to back. They should be level side to side. Clamp top and bottom before drilling.
- 4** To bolt in place, drill two upper and two lower mounting holes through frame rails and frame mount. Install and tighten bolts.
- 5** Assemble engine mount as shown.

