



CP-2250

1948-52 Ford 1/2 tn Pickup Swap Kit for Small Block Ford Engine

- 1 Remove original engine and transmission.
- 2 Slide frame mounts inside frame rails and clamp into place using dimensions shown.
- 3 Check that mounts are centered side to side and front to back. They should also be level side to side. Clamp top and bottom before drilling.
- 4 To bolt in place, drill two upper and lower mounting holes through frame rails and frame mount. Install and tighten bolts.
- 5 Assemble engine mount as shown below.

