



# SB-1048PM

## 1948-54 Chevy Pickup Front Sway Bar

For use with (non-CE) weld-on Pinto Mustang IFS

- 1** Directions assume the use of a weld-on Pinto/Mustang IFS crossmember. Since these kits vary by manufacturer, adjust given measurements as needed.
- 2** Use sway bar mounting brackets provided with kit. Clamp sway bar in place with lower lip of mounting bracket, 3/8" below the bottom of the frame rail. Doublecheck clearances and drill holes.
- 3** Now bolt sway bar in place. Use drawing as guide. The dip in the center of the sway bar points down.
- 4** Bolt sway bar lower mount to Pinto Mustang lower arm as shown below. Use original strut rod bolts. Offset in lower mount should point inward.
- 5** Move bar thru its arc. Check for interference again. Assemble linkage as shown below.

