



AS-1052

1941-48 Chevy Bolt-on Power Brake Adapter

use with Chassis Engineering AS-1041 and AS-2075

- 1 Install CE Master Cylinder and Pedal Mount AS-1041 as per instructions.
- 2 Place power brake adapter on top of crossmember and bolt to AS-1041.
- 3 Clamp tab on one side with vice grips or clamp. Locate hole to be drilled on bottom and center punch to mark hole.
- 4 Drill up from bottom of crossmember. Drill through crossmember and through tab on AS-1052
- 5 Move clamp to side just drilled, mark, locate and drill other side.
- 6 Install bolts, nuts and lock washers.
- 7 Install booster and setup linkage. Be sure pedal operates through full stroke without binding. Adjust linkage as needed. Note: Linkage must be fabricated by installer.

Note: it is the installers responsibility to see that all brake components operate correctly and without interference or binding.

