



ES-1164 ES-1166

1940-47 Chevy Pickup Transmission Mount Kit

ES-1164 for Turbo 350, Powerglide and Manual,

ES-1166 for Turbo 700 Transmission

- 1** Remove original crossmember. Exercise care in the removal of rivets as these holes will be used again.
- 2** Put new crossmember in same place, place spacer plates, one per side, between frame and square flange of crossmember.
- 3** Ream drill original holes to 3/8 inch.
- 4** Bolt the new crossmember in place.
- 5** Tighten all bolts.

