



# ES-1165 ES-1167

## 1948-54 Chevy Pickup Transmission Mount Kit

ES-1165 for Turbo 350, Powerglide and Manual,

ES-1167 for Turbo 700 Transmission

- 1** Remove original crossmember. Exercise care in the removal of rivets as these holes will be used again.
- 2** Put new crossmember in same place.
- 3** Ream drill original holes to 3/8 inch.
- 4** Bolt the new crossmember in place.
- 5** Tighten all bolts.

