



# AS-1049

## 1949-54 Chevy Bolt-on Brake Pedal Adapter

for use with Pinto Mustang Master Cylinder (and others with same pattern)  
CE part AU-2036 (15/16inch), AU-2037S (1 inch)

- 1 Remove old master cylinder with pedals.
- 2 Place new unit in same location, using original mounting holes as locators. There are matching 3/8 inch holes in the new mount.
- 3 Drill remaining holes and bolt in place.
- 4 Remove brake pedal from original master cylinder by removing plug on front of unit. Pull retainer from hole. Brake pedal will now slide out the side.
- 5 Install brake pedal in new mount. Tighten set screw until it bottoms. Important: be sure set screw is in slot on pivot shaft. Loosen set screw until brake just pivots freely on shaft. Lock set screw in place with jam nut.
- 6 Be sure pedal operates through full stroke without binding. Adjust linkage as needed. Note: Linkage provided is for Pinto Mustang cylinders. Others may not fit without modification.

**Note:** it is the installers responsibility to see that all brake components operate correctly and without interference or binding.

