



# CP-1109PM

## 1949-54 Chevy Car Small Block Chevy Engine Mount Kit (using non CE Pinto Mustang Front Suspension)

- 1 Remove original engine and transmission. Remove transmission cover in floor for access. Cut the two braces from inside of rails that interfere with engine mounting. As you progress you will find other odd pieces that will need to be removed or trimmed for clearance and fit.

### Engine Mounting (CP-1109PM)

- 2 Slip both frame adapters over frame and locate as shown.

