



AU-2075 AU-2076

Mount Spacers For Use On Power Rack And Pinion Only

Assemble as per diagram below and check clearances.

The rubber bushing is made to be longer than the inner steel sleeve. Therefore, do not cut it off at the rack and pinion housing surface.

Assemble and tighten.

